



TECHNICAL BULLETIN #2

Date: March 26, 2009

Regarding: Use of Sure Stop 350® Gaskets in Casings

Reference: Old Sure Stop 350® Gasket Brochure “Application Note #13”:
Do not use Sure Stop 350® Gaskets in Casings.

This bulletin addresses acceptable use of Sure Stop 350® gaskets in casings.

If Sure Stop 350® gaskets are to be used as a pipeline restraint in straight casings:

Pipe should be pulled through the casing. Do not push through the casing. If pipe are pushed through the casing, full homing of the spigot will occur. Once homed, joint deflection is not achievable without increased risk of gasket failure.

If pushing is the only option, please refer to TR Flex®Pipe for joint restraint.

Contact your local Sales Representative for more information.
